
Chapter 12: Phase Transformations

ISSUES TO ADDRESS...

• Transforming one phase into another takes time.



- How does the rate of transformation depend on time and temperature?
- Is it possible to slow down transformations so that non-equilibrium structures are formed?
- Are the mechanical properties of non-equilibrium structures more desirable than equilibrium ones?



Classifications of Phase Transformation

• Small Diffusion-dependent Transformation

- no change in number or composition of the phases presented
- e.g., pure metal, allotropic transf., recrystallization and grain growth
- Diffusion-dependent Transformation

some alteration in phase composition and in the number of phases present e.g., eutectoid reaction.

Diffusionless Transformation

e.g., martensitic transformation.



Phase Transformations

Nucleation

- nuclei (seeds) act as templates on which crystals grow
- for nucleus to form rate of addition of atoms to nucleus must be faster than rate of loss
- once nucleated, growth proceeds until equilibrium is attained

Driving force to nucleate increases as we increase ΔT

- supercooling (eutectic, eutectoid)
- superheating (peritectic)

Small supercooling → slow nucleation rate - few nuclei - large crystals

Large supercooling → rapid nucleation rate - many nuclei - small crystals

Solidification: Nucleation Types

Homogeneous nucleation

- nuclei form in the bulk of liquid metal
- requires considerable supercooling (typically 80-300°C)


Heterogeneous nucleation

- much easier since stable "nucleating surface" is already present e.g., mold wall, impurities in liquid phase
- only very slight supercooling (0.1-10°C)


Kinetics of Phase Transformations

- The total free energy change for the system is the sum of the two factors.
 - The volume free energy goes up as the cube of the radius
 - The surface free energy goes up as the square of the radius $Volume = \frac{4}{3}\pi r^3$

$$\Delta G(r) = \frac{4}{3}\pi r^3 \Delta G_v + 4\pi r^2 \gamma$$



Homogeneous Nucleation & Energy Effects



 $r^* =$ critical nucleus: for $r < r^*$ nuclei shrink; for $r > r^*$ nuclei grow (to reduce energy)


Adapted from Fig.10.2(b), Callister & Rethwisch 8e.

Effect of Temperature on Volume Free Energy Change (Driving Force)

$$\Delta G_v = \Delta H_f - T\Delta S = \Delta H_f (T_m - T) / T_m$$

 ΔH_f : latent heat of fusion (the heat given up during solidification)

 T_m : the equilibrium solidification temperature



Solidification

$$\frac{r^*}{\Delta H_f \Delta T}$$

 r^* = critical radius

 γ = surface free energy

 T_m = melting temperature

 ΔH_f = latent heat of solidification


 $\Delta T = T_m - T =$ supercooling

Note: ΔH_f and γ are weakly dependent on ΔT

 \therefore r decreases as ΔT increases

For typical ΔT $r^* \sim 10 \text{ nm}$

Influence of Increasing Undercooling




Free-energy-versus-embryo/nucleus-radius curves for two different temperatures.




Chapter 10 - 9

Nucleation rate v.s. Temperature



Heterogeneous Nucleation


$$r^* = (-\frac{2\gamma T_m}{\Delta H_f}) \cdot (\frac{1}{T_m - T}), \ \Delta G^* = (\frac{16\pi \gamma^3 T_m^2}{3\Delta H_f^2}) \cdot \frac{1}{(T_m - T)^2}$$




Surface or interface

$$\gamma_{\rm IL} = \gamma_{\rm SI} + \gamma_{\rm SL} \cos \theta$$

$$\Delta G_{het} = \Delta G_{hom} \times S(\theta)$$




Homogeneous v.s Heterogeneous Nucleation



Overall Transformation Rate

Growth

Particle growth occurs by atomic diffusion




Rate of Phase Transformations

Kinetics - study of reaction rates of phase transformations


• To determine reaction rate – measure degree of transformation **as function of time** (while holding temp constant)

How is degree of transformation measured?

- X-ray diffraction many specimens required
- electrical conductivity measurements on single specimen
- measure propagation of sound waves on single specimen



Rate of Phase Transformation



Avrami equation $\Rightarrow y = 1 - \exp(-kt^n)$ fraction time


Adapted from Fig. 10.10, Callister & Rethwisch 8e.

-k & n are transformation specific parameters


By convention

$$rate = 1 / t_{0.5}$$

transformed



Temperature Dependence of Transformation Rate



Adapted from Fig. 10.11, *Callister & Rethwisch* 8e.

(Fig. 10.11 adapted from B.F. Decker and D. Harker,

"Recrystallization in Rolled Copper", *Trans AIME*, **188**, 1950, p. 888.)

• For the recrystallization of Cu, since

$$rate = 1/t_{0.5}$$


rate increases with increasing temperature


• Rate often so slow that attainment of equilibrium state not possible!

Transformations & Undercooling

• Eutectoid transf. (Fe-Fe₃C system):

• For transf. to occur, must cool to below 727°C (i.e., must "undercool")






Adapted from Fig. 9.24, Callister & Rethwisch 8e. (Fig. 9.24 adapted from Binary Alloy Phase Diagrams, 2nd ed., Vol. 1, T.B. Massalski (Ed.-in-Chief), ASM International, Materials Park, OH, 1990.)

The Fe-Fe₃C Eutectoid Transformation

• Transformation of austenite to pearlite:


Austenite (γ) cementite (Fe₃C) grain Ferrite (α) boundary pearlite Adapted from Fig. 9.15, growth Callister & direction Rethwisch 8e.

Diffusion of C during transformation



For this transformation, rate increases with

 $[T_{
m eutectoid} - T]$ (i.e., ΔT).



Adapted from Fig. 10.12, Callister & Rethwisch 8e.

Coarse pearlite → formed at **higher** temperatures – relatively soft


→ formed at lower temperatures – relatively hard Fine pearlite



Generation of Isothermal Transformation Diagrams


Consider:

- The Fe-Fe₃C system, for $C_0 = 0.76$ wt% C
- A transformation temperature of 675°C.



Austenite-to-Pearlite Isothermal Transformation


- Eutectoid composition, $C_0 = 0.76$ wt% C
- Begin at T > 727°C
- Rapidly cool to 625°C
- Hold *T* (625°C) constant (isothermal treatment)




Adapted from Fig. 10.14, Callister & Rethwisch 8e. (Fig. 10.14 adapted from H. Boyer (Ed.) Atlas of Isothermal Transformation and Cooling Transformation Diagrams, American Society for Metals, 1997, p. 28.)

Bainite: Another Fe-Fe₃C Transformation Product


- Bainite:
 - -- elongated Fe₃C particles in a-ferrite matrix
 - -- diffusion controlled
- Isothermal Transf. Diagram,





Adapted from Fig. 10.17, Callister & Rethwisch 8e. (Fig. 10.17 from Metals Handbook, 8th ed., Vol. 8, Metallography, Structures, and Phase Diagrams, American Society for Metals, Materials Park, OH, 1973.)


Isothermal Transformation Diagram for Fe-C alloy of eutectoid composition



Spheroidite: Another Microstructure for the Fe-Fe₃C System

• Spheroidite (球化鐵):


- -- Fe₃C particles within an a-ferrite matrix
- -- formation requires diffusion
- -- heat bainite or pearlite at temperature just below eutectoid for long times
- -- driving force reduction of α -ferrite/Fe₃C interfacial area



Adapted from Fig. 10.19, *Callister & Rethwisch 8e.* (Fig. 10.19 copyright United States Steel Corporation, 1971.)

Martensite: A Nonequilibrium Transformation Product


- Martensite
 - -- γ (FCC) to Martensite (BCT)



x C atom sites

Adapted from Fig. 10.20, Callister & Rethwisch 8e.

• Isothermal Transf. Diagram




Martensite needlesAustenite

Adapted from Fig. 10.21, *Callister & Rethwisch &e.* (Fig. 10.21 courtesy United States Steel Corporation.)

- γ to martensite (M) transformation..
 - -- is rapid! (diffusionless)
 - -- % transf. depends only on *T* to which rapidly cooled



The Complete Isothermal Transformation Diagram for Fe-C alloy






Phase Transformations of Alloys

Effect of adding other elements


Change transition temp.

Cr, Ni, Mo, Si, Mn

retard $\gamma \rightarrow \alpha + \text{Fe}_3\text{C}$ reaction (and formation of pearlite, bainite)



Adapted from Fig. 10.23, Callister & Rethwisch 8e.




Isothermal Heat Treatment Example Problems

EXAMPLE PROBLEM 10.2

Microstructural Determinations for Three Isothermal Heat Treatments

Using the isothermal transformation diagram for an iron–carbon alloy of eutectoid composition (Figure 10.22), specify the nature of the final microstructure (in terms of microconstituents present and approximate percentages) of a small specimen that has been subjected to the following time–temperature treatments. In each case assume that the specimen begins at 760°C (1033 K) and that it has been held at this temperature long enough to have achieved a complete and homogeneous austenitic structure.

- (a) Rapidly cool to 350°C (623 K), hold for 10⁴ s, and quench to room temperature.
- **(b)** Rapidly cool to 250°C (523 K), hold for 100 s, and quench to room temperature.
- (c) Rapidly cool to 650°C (923 K), hold for 20 s, rapidly cool to 400°C (673 K), hold for 10³ s, and quench to room temperature.




- (a) 100% bainite
- (b) 100% martensite
- (c) 50% pearlite 50% bainite


Continuous Cooling Transformation (CCT) Diagrams

Conversion of isothermal transformation diagram to continuous cooling transformation diagram


Adapted from Fig. 10.25, Callister & Rethwisch 8e.




Continuous Cooling Transformation Diagrams



Mechanical Props: Fine Pearlite vs. Coarse Pearlite vs. Spheroidite






• Hardness: fine > coarse > spheroidite

• %RA: fine < coarse < spheroidite

Adapted from Fig. 10.30, Callister & Rethwisch &e. (Fig. 10.30 based on data from Metals Handbook: Heat Treating, Vol. 4, 9th ed., V. Masseria (Managing Ed.), American Society for Metals, 1981, pp. 9 and 17.)

Mechanical Props: Fine Pearlite vs. Martensite




Adapted from Fig. 10.32, Callister & Rethwisch 8e. (Fig. 10.32 adapted from Edgar C. Bain, Functions of the Alloying Elements in Steel, American Society for Metals, 1939, p. 36; and R.A. Grange, C.R. Hribal, and L.F. Porter, Metall. Trans. A, Vol. 8A, p. 1776.)

• Hardness: fine pearlite << martensite.

Tempered Martensite

Heat treat martensite to form tempered martensite

- tempered martensite less brittle than martensite
- tempering reduces internal stresses caused by quenching



- tempering produces extremely small Fe_3C particles surrounded by α .
- tempering decreases TS, YS but increases %RA



304 Stainless Steel













本商品規格品 名:鍋寶超真空保溫杯

型 號: SVC-5090C---材質: 瓶身/高級不銹鋼) 上蓋/耐熱PP(聚丙烯.耐熱135℃)

滿水容量:500c.c. 保温容量: 470c.c.


重量:約315g 產地:中國







Summary of Possible Transformations



ANNOUNCEMENTS

Reading:

Core Problems:

Self-help Problems: